

# SAFECALL SECURITY™ – QUICK USER GUIDE

## ENTER FULL ARMING MODE

### Using Pocket Remote –

- 1) Press the **MODE** button on the Pocket Remote
- 2) Within a few seconds you will hear one chirp as a confirmation tone, and the setting is accomplished

### Using the keypad on the Control Panel –

- 1) Enter the **S** key
- 2) Enter your new (or default) Passcode: **x x x x**  
(One beep = correct entry / Three quick beeps = incorrect entry must be re-entered)
- 3) Wait until the LED displays “S”
- 4) Enter the **1** key (Command Code for this function)
- 5) Within a few seconds after the confirmation tone you will hear one beep, and the setting is accomplished

## ENTER PARTIAL ARMING MODE

Partial Arming Mode can only be entered using the keypad on the Control Panel as follows:

- 1) Enter the **S** key
- 2) Enter your new (or default) Passcode: **x x x x**  
(One beep = correct entry / Three quick beeps = incorrect entry must be re-entered)
- 3) Wait until the LED displays “S”
- 4) Enter the **#** key (Command Code for this function)
- 5) Within a few seconds after the confirmation tone you will hear one beep, and the setting is accomplished

**NOTE:** When entering Full Arming & Partial Arming Modes, the unit will emit countdown beeps after the confirmation tone.

## ENTER DISARMING MODE

### Using Pocket Remote –

- 1) Press the **MODE** button on the Pocket Remote
- 2) Within a few seconds you will hear three chirps as a confirmation tone, and the setting is accomplished

### Using the keypad on the Control Panel –

- 1) Enter the **S** key
- 2) Enter your new (or default) Passcode: **x x x x**  
(One beep = correct entry / Three quick beeps = incorrect entry must be re-entered)
- 3) Wait until the LED displays “S”
- 4) Enter the **0** key (Command Code for this function)
- 5) Within a few seconds after the confirmation tone you will hear three beeps, and the setting is accomplished

## ENTER EMERGENCY/PANIC ALARM

This function is used to activate the alarm during an on-site emergency or panic situation.

### Using Pocket Remote –

- 1) Press the **PANIC** button on the Pocket Remote
- 2) The system will immediately activate the alarm, sound the siren and immediately begin dialing the programmed phone numbers

### Using the keypad on the Control Panel –

- 1) Press the **PANIC** button on the control panel
- 2) The system will immediately activate the alarm, sound the siren and immediately begin dialing the programmed phone numbers

## RESPONDING TO AN ALARM NOTIFICATION CALL

- 1) Upon an alarm activation, the system will immediately call the first programmed phone number of your choice
- 2) Answer the call, then wait for the pre-recorded Alarm Notification Message to finish playing
- 3) When you hear the confirmation tone, within 10 seconds press a key for the desired function as follows:
  - Press **4** to Monitor/Listen in
  - Press **5** to Speak via 2-way Speakerphone
  - Press **6** to have system Hang up and Dial Next Programmed Phone Number
  - Press **7** to Replay the Alarm Notification Message
  - Press **8** to have system Stop Dialing all Programmed Phone Numbers, Disconnect Call and Reset Alarm

## REMOTE ACCESS FROM ANY OUTSIDE TELEPHONE

- 1) Call the phone number that is connected to the Control Panel
- 2) Wait for the system to answer in correct amount of rings (as specified while programming Remote Call-In Ring Cycle)
- 3) When you hear the confirmation tone, enter your new (or default) Passcode: **x x x x**  
**NOTE: If you enter an incorrect Passcode, you will hear three beeps and the telephone line will hang up)**
- 4) When you hear the confirmation tone, within 10 seconds press a key for the desired function as follows:
  - Press **1** to Enter Full Arming Mode
  - Press **0** to Enter Disarming Mode
  - Press **#** to Enter Partial Arming Mode
  - Press **4** to Monitor/Listen in
  - Press **5** to Speak via 2-way Speakerphone
  - Press **8** to Disconnect

## CLEARING ALARM NOTIFICATION WARNING BEEPS

When disarming system after any Alarm Activation, the Control Panel will beep (one beep per second) to remind the user that an alarm has been activated, and the MODE/MEMO LED lights steady.

- To shut off the warning beeps, push any key on the keypad

## CUSTOMER SUPPORT

If you need help installing, programming or operating SAFECALL SECURITY™, please contact our Customer Support Center at the toll free phone number or email address listed below:

Phone: 1-800-503-4910 Email: support@dtexx.com Website: www.dtexx.com

